

From Mars Gaming team:
we want to thank you for the purchase of this product!
We try to improve everyday to offer the best service and the best quality on our peripherals. Thank you for your trust!




ARE YOU HAPPY WITH YOUR PURCHASE?

YES




Rate us in your marketplace and
share your experience in your
social media



 @MarsGaming_
 marsgaming
 MarsGamingOfficial

NO




Please contact our technical
support service by sending an
e-mail to



 support@marsgaming.eu

MARS GAMING
G A M E R S U N I V E R S E


User Guide




MS7
SPEAKER

The MS7 is a 20W speaker system with 5.0 Bluetooth and Jack connection that gives the best sound experience for your videogames, movies, series and music. This manual shows all the features of the MSX: please, keep this sheet for future reference.

A. BUTTONS

Tap the  button to switch ON and switch between Bluetooth and AUX mode. Press and hold the button for 3 seconds to switch OFF the speaker.

Tap the  button to increase/decrease volumen

Tap the  tactile icon to switch between lighting effects

B. AUX MODE

Play through Jack connection:

1. Connect the USB cable to power the speaker
2. Connect the Jack audio connector to the device desired to play the music

C. BLUETOOTH MODE

Once the bluetooth mode is activated MS7 can be connected to any Bluetooth device. Follow these steps to connect your device via bluetooth:

1. Press Power button to select Bluetooth mode. A sound notification will pop up
2. Enable the Bluetooth mode in your device and search "MS7" in the Bluetooth list
3. Play the audio you want to listen

FREQUENTLY ASKED QUESTIONS

Unsuccessful Bluetooth connection

1. Make sure the speaker is in Bluetooth mode
2. Make sure the speaker is not connected to another device
3. Check if there are too many Bluetooth devices working in the area, it can interfere its connection
4. Try to restart the Bluetooth of your device and reconnect to the speaker again

Sound distortion

1. Check the volume of the speaker and the Bluetooth device
2. Check if the speaker is properly connected and reconnect it if necessary

Stuttering music

1. Check if the device is too far from the Bluetooth device.
2. Check if there is any obstacle between the speaker and the device

Please, keep this sheet for future references.
Visit www.marsgaming.eu for more info about your product

WWW.MARSGAMING.EU