



User's Manual  
Manual de usuario  
Handbuch

Manuel d'utilisation  
Manuale utente  
Manual do usuário

Instrukcja obsługi  
Gebruikershandleiding  
Руководство пользователя

## Accessory Bag Contents



Side panel Screw



MB Standoff



HDD Screw



SSD Screw  
MB Screw




PSU Screw  
PCI Screw

## Front I/O Panel Cable Connection


(Please refer to the motherboard's manual for further instructions).

### Front Panel Connector



Motherboard

## How to Install Guide



## 1 Motherboard

**EN**

Install Motherboard

**ES**

Instalación de Placa madre

**DE**

Motherboard installieren

**FR**

Installer carte mère

**IT**

Installazione della scheda madre

**PT**

Instalar a placa principal

**PL**

Instalacja płyty głównej


**NL**

Installeer het moederbord

**RU**

Установка материнской платы

## 2 PSU



**EN**

Install PSU

**ES**

Instalación de Fuente

**DE**

Netzteil installieren

**FR**

Installer unité d'alimentation

**IT**

Installazione della PSU

**NL**

Installeer PSU

**RU**

Установка блока питания


**PT**

Instalar a fonte de alimentação

**PL**

Instalacja zasilacza


3 3.5" HDD x 2




**RU**  
Установите 3,5-дюймовый жесткий диск

- EN**  
Install 3.5" HDD
- ES**  
Instalación de 3.5" HDD
- DE**  
3,5-Zoll-Festplatte installieren
- FR**  
Installer disque dur 3,5"
- IT**  
Installare l'unità HDD 3,5"
- PT**  
Instalar o HDD de 3,5"
- PL**  
Instalacja HDD 3,5"
- NL**  
Installeer 3,5 "HDD

4 2.5" SSD x 2




- EN**  
Install 2.5" SSD
- DE**  
2,5-Zoll-SSD installieren
- ES**  
Instalación de 2.5" SSD
- FR**  
Installer SSD 2,5"



- IT**  
Installare l'unità SSD 2,5"
- PT**  
Instalar o SSD 2,5"
- PL**  
Instalacja SSD 2,5"
- NL**  
Installeer SSD 2,5"
- RU**  
Установщик SSD 2.5"

5 Radiator




**NL**  
Installeer de radiator

**RU**  
Установить радиатор

- EN**  
Install the radiator
- ES**  
Instalar el radiador
- DE**  
Heizkörper installieren
- FR**  
Installation du radiateur
- IT**  
Installazione del radiatore
- PT**  
Instalar o radiador
- PL**  
Instalacja radiatora

6



- EN**  
Connect MOLEX to PSU
- ES**  
Conectar MOLEX a la PSU
- DE**  
Verbinden Sie MOLEX mit dem Netzteil
- FR**  
Connectez MOLEX à PSU
- IT**  
Connetti MOLEX a PSU
- PT**  
Conecte o MOLEX à PSU
- PL**  
Podłącz MOLEX do zasilacza
- NL**  
Sluit MOLEX aan op PSU
- RU**  
Подключите MOLEX к блоку питания